

MTH800 & MTH900

The hygienic way to dry protective masks



The hygienic way to dry protective masks. The gentle drying process takes approx. 1 - 2 hours. Due to the exact configuration of the air vents and the ideal round ends of the handles, each one of the 8 or 9 masks receives sufficient warm air.

Advantages

- efficient drying
- gentle to the material
- 8 or 9 handles with special placement of the air vents

Optional accessories & upgrades

- couplers for drying up to 9 breathing tubes (medium pressure tubes)
- 6 hour clock timer
- foot for free standing unit

Technical details

- electr. connection: 230V~/50Hz (Euro plug)
- made of high-grade steel
- maintenance free radial fan
- 4 hour clock timer



4 hour
clock timer



plug ready



easy installation



couplers for
breathing tubes

	MTH 800	MTH 900
height (in mm)	475	475
width (in mm)	730	730
depth (in mm)	325	325
weight (in kg)	8	8
power consumption (watts)	130	135